


Pushbutton Guide for Masoneilan* 12400 Level Transmitter

Revision: 112

Pushbutton Guide for Masoneilan* 12400 Level Transmitter



The chart colors represent the control mode of the 12400 in which the function is available:

- Red: Normal Operating Mode
- Blue: Setup Mode
- Green: View Data /Error Mode


Please consult Masoneilan* 12400 Instruction Manual for complete details on the device features and functions.

HART* Handheld Communicator Guide for Masoneilan* 12400 Level Transmitter



HART* Handheld Communicator Guide for Masoneilan* 12400 Level Transmitter

Revision: 112



The chart colors represent the control mode of the 12400 in which the function is available:

Red: Normal Operating Mode
 Blue: Setup Mode
 Green: View Data /Error Mode

Please consult Masoneilan* 12400 Instruction Manual for complete details on the device features and functions.

www.ge-energy.com

* Masoneilan is registered trademark of the General Electric Company. Other company names and product names used in this document are the registered trademarks or trademarks of their respective owners.

© 2011 General Electric Company. All rights reserved.

GEA19664 12/2011

[Formerly Dresser ID: GW12400]